

APPROACH BUILDING POLICY
THE RURAL MUNICIPALITY OF PROGRESS NO. 351

When approving well sites for oil and gas companies who want to build an approach off of one of the RM roads, the company must make sure that:

1. No approach shall be constructed where sight distance is inadequate or where so approach would create hazardous traffic movement.
2. Culverts are to be installed in the approaches as per the specifications and placement of council and/or Saskatchewan water corporation.
3. The width of the approach shall be constructed at no less than 20 metres wide.
4. No material from the road to be used in the construction of the approach.